

Window Closer User's Manual

Function:

1. At most 4 windows shall be closed one by one automatically when the engine is stopped and the car doors are locked.
2. The item is suitable for the following cars: Toyota, MAZDA, BUICK, FORD, LEXUS,
3. There is positive and negative trigger function for your option according to your original car central locking or car alarm trigger way. The 5P wires: blue wire is the positive trigger; orange wire is the negative trigger. Notice: don't connect the 2 wires at the same time.
4. The system has the major circuit positive or negative controlled function for your option. The major negative or positive circuit is controlled individually via the thick red wire from the 10P wires.
5. The major chip in the system is imported from USA, which is stable and easy to use and reliable as well as durable.
6. All the unwanted wires must be wrapped up, don't connect them with any other car parts and car body to avoid the bad affection.
7. Don't connect each wire wrong. For detailed installation, please read the Installation diagram.

SPECIFICATIONS

1. Power supply: +12V
 2. Static current: 5mA
 3. Maximum power output with the window motor relay: 15A
- Numbers of window controllable: 4 windows

Diagram 1




Diagram 2

